


Save These Instructions!
Conservez ces instructions!
Bewahren Sie diese Anweisungen auf.
Conservare questo manuale!
Guarde estas instruções!
Φυλάξτε αυτές τις οδηγίες!
¡Guarde estas instrucciones!
Bewaar deze gebruiksaanwijzing!
请保存好本说明!

TOSHIBA



TCB-CC163TLE2

ON-OFF Controller

Contrôleur marche-arrêt

Ein-AUS-Steuergerät

Comando acceso-spento

Controlador de ligação-desligação

Ελεγκτής ΕΝΤΟΣ-ΕΚΤΟΣ

Controlador de encendido-apagado

ON-OFF-afstandsbediening

ON-OFF控制器

• **INSTRUCTION MANUAL**

• **MODE D'EMPLOI**

• **BEDIENUNGSANLEITUNG**

• **ISTRUZIONI PER L'USO**

• **MANUAL DE INSTRUÇÕES**

• **ΕΓΧΕΙΡΙΔΙΟ ΟΔΗΓΙΩΝ**

• **MANUAL DE INSTRUCCIONES**

• **HANDLEIDING**

• **使用说明书**

EG

F

D

I

P

GR

ES

NE

CS

Contents

	Page
Product Information.....	2
Installation Location.....	3
Electrical Requirements.....	3
Safety Instructions.....	3
How to Use the ON-OFF Controller.....	4
■ Functions of buttons.....	4
■ How to use the nameplate.....	5

Product Information

If you have problems or questions concerning your Air Conditioner, you will need the following information. Model and serial numbers are on the nameplate on the bottom of the cabinet.

Model No. TCB-CC163TLE2 Serial No. _____

Date of purchase _____

Dealer's address _____

Phone number _____

Installation Location

- We recommend that this ON-OFF controller be installed properly by qualified installation technicians in accordance with the Installation Instructions provided with the ON-OFF controller.



WARNING

- Do not install this ON-OFF controller where there are fumes or flammable gases, or in an extremely humid space such as a greenhouse.
- Do not install the ON-OFF controller where excessively high heat-generating objects are placed.

Electrical Requirements


1. All wiring must conform to the local electrical codes. Consult your dealer or a qualified electrician for details.
2. Wiring must be done by a qualified electrician.



CAUTION

To warm up the system, the power mains must be turned on at least five (5) hours before operation. Leave the power mains ON unless you will not be using this appliance for an extended period.

Power mains



ON

Safety Instructions

- Read this booklet carefully before using this ON-OFF controller. If you still have any difficulties or problems, consult your dealer for help.
- The air conditioner is designed to give you comfortable room conditions. Use this only for its intended purpose as described in the Instruction Manual.



WARNING

- Never touch the unit with wet hands.
- Never use or store gasoline or other flammable vapor or liquid near the air conditioner — it is very dangerous.
- The air conditioner has no ventilator for intaking fresh air from outdoors. You must open doors or windows frequently when you use gas or oil heating appliances in the same room, which consume a lot of oxygen from the air. Otherwise there is a risk of suffocation in an extreme case.




CAUTION




- Do not turn the air conditioner on and off from the power mains switch. Use the ON/OFF operation button.
- Do not stick anything into the air outlet of the outdoor unit. This is dangerous because the fan is rotating at high speed.
- Do not let children play with the air conditioner.
- Do not cool or heat the room too much if babies or invalids are present.

EG

How to Use the ON-OFF Controller

■ Functions of buttons



<p>A: ON/OFF button</p> <p>01 ~ 16</p> 	<p>Press this to start up or stop an individual air conditioner.</p>
<p>B: All ON button</p> <p>ALL ON · I</p>  <p>NOTE</p>	<p>Press this to start up all the air conditioners at the same time.</p> <p>The indoor units which can be operated by the ON-OFF controller now start operating in sequence at intervals of 1 to 2 seconds.</p>
<p>C: All OFF button</p> <p>ALL OFF · O</p> 	<p>Press this to stop all the air conditioners at the same time.</p>

■ How to use the nameplate

The nameplate shows the rooms where the air conditioners are to be operated, and it enables the operating statuses of the air conditioners in those rooms to be checked by the operation indicator lamps.

Steps

1. Insert an implement such as a ballpoint pen into the hole on the left of the transparent cover, and remove the cover.
2. Use a writing instrument such as an oil-based pen to write the names of the rooms on the switch name labels provided, and adhere the labels to the name displays.

